


Dynisco model 1480 and 1490 wiring & quick start instructions (for millivolt transducers)


Terminal Schematic:



Terminal connections:

Terminal number	Wire color	6 Pin	8 Pin
2 (Sig +)	Red	A	B
3 (Sig -)	Black	B	D
4(Exc +)	White	C	A
5(Exc -)	Green	D	C
6 (Rcal)	Blue	E	E
7 (Rcal)	Orange	F	F
			G (no connection)
			H (no connection)

Milivolt transducer electrical connections:













Set up parameters:




Note: At first power-up the message **Go to Conf** is displayed, as described in section 3 of this manual. Access to other menus is denied until configuration mode is completed



2. SELECT MODE

Select mode is used to access the configuration and operation menu functions. It can be accessed at any time by holding down  and pressing . The **SELCt** legend is shown for 1 second, followed by the legend for the current mode. Press  or  to choose the required mode, then press  to enter. An unlock code is required to prevent unauthorised entry to Configuration, & Setup modes. Press  or  to enter the unlock code, then press  to proceed.

Mode	Legend <i>for 1 sec followed by</i>	Set Value	Description	Default Unlock Codes
Operator	SELCt	OPtR	Normal operation	None
Set Up		SEtUP	Tailor settings for application	10
Configuration		ConF	Configure instrument for use	20
Product Info		inFo	Instrument information	None
Calibration		UCAL	Calibrate Strain Gauge input	10
Special		SPECL	Special	None

Procedure

Press  or  to choose the required mode, then press  to enter.

1. Enter “ConF” via select menu
2. Unlock code is 20(press  till you see 20, then press )
3. Continue through section 3 below, for parameter settings
(default input is STR_G for strain gauge)



3. CONFIGURATION MODE

First select Configuration mode from Select mode (refer to section 2).
 Press **⏪** to scroll through the parameters. *While this key is pressed, and up to 1 second after, the parameter legend is shown, followed by the current value.*
 Press **⬆** or **⬇** to set the required value. Press **⏪** to display **YES**, press **⬆** accept the change, otherwise parameter will revert to previous value. To exit from Configuration mode, hold down **⏪** and press **⬆** to return to Select mode.
*Note: Parameters displayed depend on how instrument has been configured. Refer to user guide (available from your supplier) for further details. Parameters marked * are repeated in Setup Mode.*

Parameter	Legend <small>for 1 sec followed by →</small>	Set Value	Adjustment Range & Description	Default Value	
Mode Default	dF P7	d ISA EnAb	Enables or Disables Defaulting of Values within Mode	d ISA	
Input Range/Type	inPut	<i>See following table for possible codes</i>		Str_G	
Code	Input Type & Range	Code	Input Type & Range	Code	Input Type & Range
bC	B: 100 - 1824 °C	LF	L: 32.0 - 999.9 °F	PtF	Pt100: -328 - 1472 °F
bF	B: 211 - 3315 °F	nC	N: 0 - 1399 °C	PtC	Pt100: -128.8 - 537.7 °C
cC	C: 0 - 2320 °C	nF	N: 32 - 2551 °F	PtF	Pt100: -199.9 - 999.9 °F
cF	C: 32 - 4208 °F	rC	R: 0 - 1759 °C	0_20	0 - 20 mA DC
JC	J: -200 - 1200 °C	rF	R: 32 - 3198 °F	4_20	4 - 20 mA DC
JF	J: -328 - 2192 °F	SC	S: 0 - 1762 °C	0_50	0 - 50 mV DC
JC	J: -128.8 - 537.7 °C	SF	S: 32 - 3204 °F	10_50	10 - 50 mV DC
JF	J: -199.9 - 999.9 °F	tC	T: -240 - 400 °C	0_5	0 - 5 V DC
KC	K: -240 - 1373 °C	tF	T: -400 - 752 °F	1_5	1 - 5 V DC
KF	K: -400 - 2503 °F	tC	T: -128.8 - 400.0 °C	0_10	0 - 10 V DC
KC	K: -128.8 - 537.7 °C	tF	T: -199.9 - 752.0 °F	2_10	2 - 10 V DC
KF	K: -199.9 - 999.9 °F	P24C	PtRh20% vs. 40%: 0 - 1850 °C	Str_G	-10mV-50mV
Lc	L: 0 - 762 °C	P24F	PtRh20% vs. 40%: 32 - 3362 °F		
Lf	L: 32 - 1403 °F	PtC	Pt100: -199 - 800 °C		
Lc	L: 0.0 - 537.7 °C				

Note: Decimal point shown in table indicates temperature resolution of 0.1°



Parameter	Legend <i>for 1 sec followed by</i> →	Set Value	Adjustment Range & Description	Default Value
Scale Range Upper Limit	rUL	Scale Range Lower Limit +100 to Range Maximum		Max (Lin = 1000)
Scale Range Lower Limit	rLL	Range Minimum to Scale Range Upper Limit -100		Min (Lin = 0)
Decimal point position	dPoS	0=XXXX, 1=XXX.X, 2=XX.XX, 3=X.XXX	(non-temperature ranges only)	0
*Multi-Point Scaling	r7 P5	EnAb d,SA	Enables or disables the input multi-point scaling feature	d,SA
Alarm 1Type	AL71	P_H, P_Lo	Process High Alarm Process Low Alarm	P_H,

*** Scale range upper and lower limit should match the value of the transducer that is connected***



		nonE	No alarm	
High Alarm 1*	PhA 1	Alarm 1 value, adjustable within scaled range, in display units		Max
Low Alarm 1*	PLA 1			Min
Alarm 1 Hysteresis*	AHY 1	1 LSD to full span in display units on safe side of alarm		10
Alarm 2 Type	ALTY2	Options as for alarm 1		nonE
High Alarm 2*	PhA 2			Max
Low Alarm 2*	PLA 2	Options as for alarm 1		Min
Al 2 Hysteresis*	AHY 2			10
Output 1 Usage	USE 1	rEtP	Retransmit PV Output	rEtP
		dc 10	0 to 10VDC (adjustable) transmitter power supply*	
Output 1 PV Retransmit Type	tYP 1	0_5	0 to 5 V DC output	0_10
		0_10	0 to 10 V DC output	
		2_10	2 to 10 V DC output	
		0_20	0 to 20 mA DC output	
		4_20	4 to 20 mA DC output	
Retransmit OP 1 Scale maximum	rEtHG 1	Display value between, -1999 & 99999 at which Output 1 will be at maximum		Range max
Retransmit OP 1 Scale minimum	rEtLo 1	Display value between, -1999 & 99999 at which Output 1 will be at minimum		Range min
TxPSU 1 level	PSU 1	Output 1 Power Supply (0 to 10VDC)*		10.0








Output 2A Usage	USE2A	A1 nd	Alarm 1, direct, non-latching	A Ind
		A1 nr	Alarm 1, reverse, non-latching	
		A1 Ld	Alarm 1, direct, latching	
		A1 Lr	Alarm 1, reverse, latching	
		A2 nd	Alarm 2, direct, non-latching	
		A2 nr	Alarm 2, reverse, non-latching	
		A2 Ld	Alarm 2, direct, latching	
		A2 Lr	Alarm 2, reverse, latching	
		Or 12d	Logical Alarm 1 OR 2, direct	
		Or 12r	Logical Alarm 1 OR 2, reverse	
		Any d	Any active alarm, direct	
Any r	Any active alarm, reverse			
Output 2B Usage	USE2b	As for Output 2 Usage		A2nd
Display Strategy	d ISP	0, 1, 2, 3, 4 or 6 (refer to section 8)		0
Serial Communications Protocol	Proto	r7bno	Modbus with no parity	r7bno
		r7bEn	Modbus with Even parity	
		r7bod	Modbus with Odd parity	
Serial Communication Bit Rate	bAud	1.2	1.2 Kbps	4.8
		2.4	2.4 Kbps	
		4.8	4.8 Kbps	
		9.6	9.6 Kbps	
		19.2	19.2 Kbps	
Comms Address	Addr	1	1 to 255 (Modbus)	1
Comms Write	CoEn	rLWrt	Read/Write	rLWrt
		rOnLY	Read Only	
Logic Input Usage	d iG i	rELAY	Reset latched relay(s)	rrLY
		tAR-E	Initiate Tare (zero display)	
		rESPV	Reset min/max PV values	
		rESAt	Reset Alarm 1 elapsed time	
		rPVAt	Reset Alarm 1 elapsed time & min/max PV values	
Logic Input State	d iG d	CLoSE	Close contact activates logic state	CLS
		OPn	Open contact activates logic state	
Config Lock	C Loc	Config Mode lock code, 0 to 9999		20






4. SETUP MODE

Note: Configuration must be completed before adjusting Setup parameters.

First select Setup mode from Select mode (refer to section 2). Press  to scroll through the parameters (while this key is pressed, and for 1 sec after, the parameter legend is shown, then the current value). Press  or  to change the value.

To exit from Setup mode, hold down  and press  to return to Select mode.

Note: Parameters displayed depends on how instrument has been configured.






Parameter	Legend for 1 sec followed by 	Set Value	Adjustment Range & Description	Default Value
Mode Default			Enables or Disables Defaulting of Values within Mode	







Input Filter Time Constant	<i>FILT</i>	Off or 0.5 to 100.0 secs	<i>0.5</i>
Alarm Filter time Constant	<i>ALNF</i>	0.5 to 100.0 secs	<i>0.5</i>
Input fail Mode	<i>InPFL</i>	When input fails PV should go Low or High scale reading	<i>High</i>
Process Variable Offset	<i>OFFS</i>	±Span of controller	<i>0.0</i>
Raw PV value	<i>SGNL</i>	Linear input value, un-scaled (mA, mV or VDC)	
High Alarm 1	<i>PHA 1</i>	Alarm 1 value, adjustable within scaled range, in display units	Max
Low Alarm 1	<i>PLA 1</i>		Min
Alarm 1 Hysteresis	<i>AHY 1</i>	1 LSD to full span in display units on safe side of alarm	<i>10</i>
High Alarm 2	<i>PHA 2</i>	Options as for alarm 1	Max
Low Alarm 2	<i>PLA 2</i>		Min
AI 2 Hysteresis	<i>AHY 2</i>		<i>10</i>
Scaling Breakpoint 1	<i>ScAL 1</i>	Multi-point scaling breakpoint 1 value, adjustable from <i>0</i> to <i>100</i> in % of span	<i>100</i>
Display Value 1	<i>d,SP 1</i>	Value to be displayed at multi-point scaling breakpoint 1, in display units	Range Max
Scaling Breakpoint 2	<i>ScAL2</i>	Multi-point scaling breakpoint 2, adjustable up to 100% of span. Must be > <i>ScAL 1</i> value	
Display Value 2	<i>d,SP2</i>	Value to be displayed at Multi-point scaling breakpoint 2, in display units	
Scaling Breakpoint 3	<i>ScALn . 9</i>	Multi-point scaling breakpoint <i>n..9</i> , adjustable up to 100% of span. Must be > <i>ScALn . .9</i> value	
Display Value 3	<i>d,SPn . .9</i>	Value to be displayed at Multi-point scaling breakpoint <i>n..9</i> , in display units	
Tare Feature	<i>tArE</i>	<i>EnAb</i> <i>d,SA</i> Enables or disables the input auto-zero Tare feature	<i>d,SA</i>
Setup Lock Code	<i>S Loc</i>	<i>0</i> to <i>9999</i>	<i>10</i>



5. STRAIN GAUGE CALIBRATION MODE

Note: Configuration must be completed before adjusting Calibration parameters. First select Calibration mode from Select mode (refer to section 2). Press  to scroll through the parameters (while this key is pressed, and for 1 sec after, the parameter legend is shown, then the current value). Press   to change the value. To exit from Calibration mode, hold down  and press  to return to Select mode.

Note: Calibration mode will only be displayed if input type is set to Str_G

Parameter	Legend <i>for 1 sec followed by</i>	Set Value	Adjustment Range & Description	Default Value
Mode Default	dF n7	d,SA EnAb	Enables or Disables Defaulting of Values within Mode	d,SA
Shunt Resistor	Shunt	d,SA EnAb	Enables or Disables use of shunt resistor	EnAb
Calibration Resistor Value	rCAL	40% to 100% (appears only when Shunt is EnAb)		80
Start Low Calibration	CLoLw	Press  and  to start calibration		0.0
Start High Calibration	CH iGh	Press  and  to start calibration making sure to apply the high range signal if Shunt is set d,SA (Can only be accessed once a successful low calibration has been completed)		10000
Calibration Lock Code	r Loc	0 to 9999		10

When the calibration procedure begins ---- appears on the screen. Once Calibration is complete done appears on screen.

If there are any Faults with the calibration an error message will appear either ErSht or ErCAL.

ErCAL means the low calibration will fail if the offset is less than -10mV or greater than +10mV. This signifies potential faulty sensors or the high calibration will fail if the count value is less than +20mV or greater than +50mV. This signifies potential faulty sensors

ErSht means the high calibration will fail if the mV value is within 10mV of the low calibration value. This is a potential RCAL failure.